

This pattern assumes use of quilting weight cotton that is 44/45" wide. Seam allowances are 1/4" except where noted.

We are using the "Burrito" method and French Seams for no raw edges.

Cut pieces as follows:	STANDARD	QUEEN	KING
Main Body	27" x WOF	33" x WOF	37" x WOF
Cuff	10" x WOF	10" x WOF	10" x WOF
Trim/Accent	3" x WOF	3" x WOF	3" x WOF

DIRECTIONS

- 1) Cut all pieces then iron the Trim piece in half to be 1.5" wide.
- 2) Unfold the Cuff and place it Right Side UP.
- 3) Unfold and place the **Body also Right Side UP on top of the Cuff,** matching the center fold and aligning the raw edges.
- 4) Place the **Trim on top of the Body** matching raw edges. Place a few pins.
- 5) **BURRITO:** Beginning on the opposite raw edge of the Body, roll it up toward the pinned edge, stopping about 2" from the edge with the pins.
- 6) Fold the bottom of the Cuff up to meet the other raw edges. Add lots more pins, pins, pins. *Be careful not to catch the rolled Body in the pins.*
- 7) Sew along the pinned edge. Pull the Body out of the tube and Press.
- 8) Fold the pillowcase in half, neatly, (selvedge to selvedge) taking care to especially align the top folded ends of the Cuff.
- 9) Align the folded edge with a line on your cutting mat, then cut the selvedge edges off .
 Anywhere around 21" from the fold is fine.
 Don't sweat it. It is perfectly okay if the overall width varies from 40-42".
- 10) **FRENCH SEAMS:** Fold pillowcase in half **WST** and stitch from the Cuff edge, down the side and across the bottom.
- 11) Fold pillowcase **RST**, PRESS, then stitch from the Cuff, down the side and across bottom with a 1/2" seam allowance, encasing the 1/4" seam inside.

WST:

Wrong Sides Together **RST:**

Right Sides Together **WOF:**

Width of Fabric

QUICK REFERENCE:

Iron Trim
Cuff Right Side UP
Body Right Side UP
Trim on Body
Pin, Sew, Pull, Press
Cut off Selvedges

French Seams